

ARTOME S1

QUICK USER GUIDE


1

- Connect the power cable to the **POWER** connector on the back wall of the device (see picture A).

2

- Connect the HDMI cable to the **HDMI** connector on the back wall (see picture B).

3

- Connect the other end of the HDMI cable to the computer. Use an adapter if necessary (see picture C).

4

- Artome will start automatically when the HDMI cable is connected between the computer and Artome.
- If needed, start Artome from the **POWER** button on the control panel.

ADJUSTING IMAGE FOCUS



Open the front door by pressing the top left front corner. The image focus adjustment lever is located behind the hatch on the side of the projector. Push the locking mechanism forward (1) to open the hatch (2). Adjust the image resolution from the adjustment lever (3).

CONTROL PANEL



PAUSE

Turns off the image and the sound
 • Image and sound restores by pressing again

FREEZE

Freezes the image, but not the sound
 • Long press activates the image zoom adjustment

VOL +/-

Adjusts the volume
 • Adjusts the image zoom when the adjustment is active

SOURCE

Selects the source between connected devices

POWER

Turns the device on and off

CONNECTIONS



HDMI


Audio and video input

MIC 1 & 2

Connection for a microphone
 or a wireless microphone
 receiver


GAIN

Microphone volume control



POWER

Main power input



HDMI

Audio and video input

DATA (if connected)

- LAN
- HDbaseT
- AV-over-IP / Dante