

ARTOME S1

QUICK USER GUIDE



1

- Connect the power cable to the **POWER** connector on the back wall of the device (see picture A).

2

- Connect the HDMI cable to the **HDMI** connector on the back wall (see picture B).

3

- Connect the other end of the HDMI cable to the computer. Use an adapter if necessary (see picture C).

4


- Artome will start automatically when the HDMI cable is connected between the computer and Artome.
- If needed, start Artome from the **POWER** button on the control panel.

ADJUSTING IMAGE FOCUS



Open the front door by pressing the top left front corner. The image focus adjustment lever is located behind the hatch on the side of the projector. Push the locking mechanism forward (1) to open the hatch (2). Adjust the image resolution from the adjustment lever (3).

CONTROL PANEL



PAUSE Turns off the image and the sound
• Press again to restore the image and the sound

FREEZE Freezes the image, but not the sound
• Long press to activate image zoom adjustment

VOL +/- Adjusts the volume
• Adjusts the image zoom when the adjustment is active

SOURCE Selects the source between connected devices
• Long press to activate audio only mode
• Press again to return to projection mode

POWER Turns the device on and off


CONNECTIONS




HDMI
Audio and video input

MIC 1 & 2
Connection for a microphone
or a wireless microphone
receiver

GAIN
Microphone volume control



POWER
Main power input



HDMI
Audio and video input

DATA (if connected)

- LAN
- HDbaseT
- AV-over-IP / Dante