

Artome M10 Projector Installation guide



1. Installer toolkit: cable harness, thumb screws, speaker cover screws, PH2 and HEX3 tools, cable ties, and rack screws.

NOTE: Cables may already be installed.



2. Compatible projector models: EB-805F, EB-800F. Lock the wheels before starting the installation.



3. Remove the back cover with HEX3 tool.



4. Push the upper-left corner to open the door. Press the hinge release to remove it, supporting the door while detaching.



5. Remove the speaker panel cover with PH2 tool.

For models with buttons in the speaker cover, also disconnect the CAT cable.



6. Remove the button cover from the projector.



7. Slide the projector inside the cabinet.



8. Lower the projector legs to alignment holes.



9. Fix the projector to cabinet with the provided thumb screws.

Artome M10

Projector Installation guide



10. Connect the following cables:
HDMI 1, PROJECTOR AUDIO, RS-232,
PROJECTOR POWER.

NOTE: Connector placement might vary.



11. Connect the cables to their
corresponding connectors on the projector.



12. Secure the cable harness with cable ties.



13. Connect HDMI 2 and 3.5 mm audio
cables to the back cover.



14. Reinstall the back cover with HEX3 tool.



15. Reinstall the speaker cover with PH2 tool.

For models with buttons in the speaker cover,
also connect the CAT cable.



16. Reinstall the door. Adjust the hinges if it's
misaligned.



17. Connect the power cable.



17. Press Power and wait 2 minutes for the
automatic setup to complete.

The device will shut down when ready.