

Getting Started



- 1 Open the door by pressing the upper left corner and connect the power cable.



- 2 Connect your laptop to the HDMI port using an HDMI cable.

Artome Remote



POWER

Turns the device on and off.

SOURCE

Selects the source between connected devices.

MENU & BACK

Opens the projector menu. Use the arrow keys to navigate. Press "Back" to go to the previous menu level.

AV MUTE (PAUSE)

Turns off the image and the sound.

VOLUME & MUTE

Adjusts the volume.

AUDIO ONLY

Activates audio only mode. Press again to return to projection mode.

FREEZE


Freezes the image, but not the sound.

Press and hold to enter lens adjustments. Pressing the button again cycles through **Focus** » **Lens Shift** » **Zoom**.

Image adjustment with Epson remote



TEST PATTERN
Select Test Pattern for clear image adjustment.




LENS SHIFT
Adjusts the image position horizontally and vertically.



ZOOM
Adjusts the image size with optical lens zoom.



FOCUS
Adjusts the image focus.



V-BALANCE*
Adjusts the image height.



V-KEystone*
Adjusts the image focus.

*Go to Menu > Settings > Geometry Correction > H/V-keystone



Control panel



PAUSE / AV MUTE

Turns off the image and the sound

FREEZE

Freezes the image, but not the sound

VOL +/-

Adjusts the volume

SOURCE

Selects the source between connected devices


POWER

Turns the device on and off

USB

Connection for USB camera

Connections



HDMI

Audio and video input

ARTOME+

Interface between video conferencing devices and a computer

USB

Connection for additional devices e.g. a wireless desktop microphone receiver

MIC 1 & 2

Connection for a wired microphone or a wireless microphone receiver. Can also be switched to Line In mode.

AUDIO OUT L & R

Audio output for external speakers (balanced stereo 0 dBV)

POWER

Connection for the mains power of the device



XLR inputs to Mic in or Line in mode

1

Press and hold the remote's 'AV Mute' button for 10s until 'AV Mute' and 'Freeze' turns red.



Blinking green 'Source' = Line in mode
Blinking green 'Power' = Mic in mode

2

Select your mode using the remote's navigation 'up' or 'down' buttons. Press 'AV Mute' to exit selection.

Download the Artome Connect app from the App Store or Google Play to easily manage audio, security, and other settings via Bluetooth.



Artome support
support@artome.fi

5.0



ARTOME